

TEXTUAL DESCRIPTION	ABBREVIATED DESCRIPTION	Expected Path Terminator Coding	Fly-Over Required
<p>NOTES APPLICABLE TO ALL STAR</p> <ul style="list-style-type: none"> - RNP1 APPROVAL REQUIRED - REQUIRED GNSS - IAS MAX 250 kt BELOW FL100 			
STAR DENER 1Y RNAV (GNSS)			
<u>DENER</u> . To SV401 (IAF) at 2500 ft.	<u>DENER</u> – SV401[A2500]	IF TF	Y -
STAR EDIPA 1Y RNAV (GNSS)			
<u>EDIPA</u> . To SV401 (IAF) at 2500 ft.	<u>EDIPA</u> – SV401[A2500]	IF TF	Y -
STAR EVKAS 1Y RNAV (GNSS)			
<u>EVKAS</u> . To SV366 at 5300 ft minimum, FL090 maximum. To SV403 (IAF) at 5300 ft.	<u>EVKAS</u> – SV366[A5300+;F090-] – SV403[A5300]	IF TF TF	Y - -
STAR NEMDO 1Y RNAV (GNSS)			
<u>NEMDO</u> . To IREDO. To SV362 at or below FL090, turn left. To SV366 at 5300 ft minimum, FL090 maximum, turn left. To SV403 at 5300 ft.	<u>NEMDO</u> – IREDO – SV362[F090-;L] – SV366[A5300+;F090-;L] – SV403[A5300]	IF TF TF TF TF	Y - - - -
STAR NINAU 1Y RNAV (GNSS)			
<u>NINAU</u> . To SV365 at or below FL080, turn right. To SV364 at 2500 ft minimum, FL080 maximum, turn right. To SV402 at 2500 ft.	<u>NINAU</u> – SV365[F080-;R] - SV364[A2500+;F080-;R] – SV402[A2500]	IF TF TF TF	Y - - -
STAR SISAU 1Y RNAV (GNSS)			
<u>SISAU</u> . To SV364 at 2500 ft minimum, FL080 maximum, turn right. To SV402 at 2500 ft.	<u>SISAU</u> – SV364[A2500+;F080-;R] – SV402[A2500]	IF TF TF	Y - -
STAR SNT 1Y RNAV (GNSS)			
<u>SNT</u> . To SV364 at 2500 ft minimum, FL080 maximum, turn left. To SV402 at 2500 ft.	<u>SNT</u> – SV364[A2500+;F080-;L] – SV402[A2500]	IF TF TF	Y - -