

SONVA TWO PAPA ARRIVAL (SONVA2P)

Inbound R-104 SNT direct to 12.0 DME SNT, turn right to join ARC 10.0 DME SNT to R-037 SNT, turn left to follow R-025 SNT direct to VOR/DME SNT (IAF).

SONVA TWO TANGO ARRIVAL (SONVA2T)

Inbound R-104 SNT direct to VOR/DME SNT (IAF).

SONVA TWO WHISKY ARRIVAL (SONVA2W)

Inbound R-104 SNT direct to 12.0 DME SNT, turn left to join ARC 10.0 DME SNT to R-205 SNT, turn right to follow R-217 SNT direct to VOR/DME SNT (IAF).

SAO VICENTE TWO PAPA ARRIVAL (SVT2P)

Inbound R-331 SNT direct to 12.0 DME SNT, turn left to join ARC 10.0 DME SNT to R-013 SNT, turn right to follow R-025 SNT direct to VOR/DME SNT (IAF).

SAO VICENTE TWO TANGO ARRIVAL (SVT2T)

Inbound R-331 SNT direct to VOR/DME SNT (IAF).

SAO VICENTE TWO WHISKY ARRIVAL (SVT2W)

Inbound R-331 SNT direct to 15.0 DME SNT, turn right to join ARC 13.0 DME SNT to R-268 SNT, turn left to join ARC 10.0 DME SNT to R-228 SNT, turn left to follow R-217 SNT direct to VOR/DME SNT (IAF).

VONTO TWO PAPA ARRIVAL (VONTO2P)

Inbound R-120 SNT direct to 12.0 DME SNT, turn right to join ARC 10.0 DME SNT to R-037 SNT, turn left to follow R-025 SNT direct to VOR/DME SNT (IAF).

VONTO TWO TANGO ARRIVAL (VONTO2T)

Inbound R-120 SNT direct to VOR/DME SNT (IAF).

VONTO TWO WHISKY ARRIVAL (VONTO2W)

Inbound R-120 SNT direct to 12.0 DME SNT, turn left to join ARC 10.0 DME SNT to R-205 SNT, turn right to follow R-217 SNT direct to VOR/DME SNT (IAF).