

SONVA ONE KILO ARRIVAL (SONVA1K)

Inbound R-104 SNT direct to 12.0 DME SNT, turn left to join ARC 10.0 DME SNT to R-204 SNT, turn right to follow 036° PRA direct to NDB PRA (IAF).

SONVA ONE BRAVO ARRIVAL (SONVA1B)

Inbound R-104 SNT direct to 12.0 DME SNT, turn right to join ARC 10.0 DME SNT to R-038 SNT, turn left to follow 207° PRA direct to NDB PRA (IAF).

SAO VICENTE ONE JULIET ARRIVAL (SVT1J)

Inbound R-331 SNT direct to 10.0 DME SNT, follow 156° PRA direct to NDB PRA (IAF).

SAO VICENTE ONE KILO ARRIVAL (SVT1K)

Inbound R-331 SNT direct to 15.0 DME SNT, turn right to join ARC 13.0 DME SNT to R-268 SNT, turn left to join ARC 10.0 DME SNT to R-228 SNT, turn left to follow 036° PRA direct to NDB PRA (IAF).

SAO VICENTE ONE LIMA ARRIVAL (SVT1L)

Inbound R-331 SNT direct to 12.0 DME SNT, turn left to join ARC 10.0 DME SNT to R-012 SNT, turn right to follow 207° PR direct to NDB PRA (IAF).

VONTO ONE JULIET ARRIVAL (VONTO1J)

Inbound R-120 SNT direct to 12.0 DME SNT, follow 296° PRA direct to NDB PRA (IAF).

VONTO ONE KILO ARRIVAL (VONTO1K)

Inbound R-120 SNT direct to 12.0 DME SNT, turn left to join ARC 10.0 DME SNT to R-204 SNT, turn right to follow 036° PRA direct to NDB PRA (IAF).

VONTO ONE LIMA ARRIVAL (VONTO1L)

Inbound R-120 SNT direct to 12.0 DME SNT, turn right to join ARC 10.0 DME SNT to R-038 SNT, turn left to follow 207° PRA direct to NDB PRA (IAF).